

#### **Installation Instructions**

80-9303-2206-010 (04-09)

## 3000 Series Tri-Style

Non Handed Door Closer

# The Habitat for Humanity®

Left Hand Door - LH

Left Hand Door - LH

Left Hand Door - LH

Right Hand Reverse - RHR

Right Hand Reverse - RHR

Right Hand Reverse - RHR

Top Jamb

Installation

See Page 5

Parallel Arm

Installation

See Pages

3 & 4

Regular Arm

Installation

See Page 2



An Incorrectly installed or improperly adjusted door closer can cause property damage or personal injury. These installation instructions should be followed to avoid the possibility of misapplication or misadjustment.


"DL" suffix (Delayed Action) is an optional feature.


**NOTE:** For special applications a separate door and frame preparation template is packed with these instructions. Use this instruction sheet for installation sequence and closer adjustments only.


- Doors should be hung on ball bearing or anti-friction hinges.
- A separate door stop is recommended.
- Door and frame must be properly reinforced.
- Always adjust spring power before adjusting control.
- Adjust closing time speed between 3 and 7 seconds from 90° to 0°. Greater closing times may be required for elderly or handicapped.
- These door closers should NOT be installed on the exposed side (weather side) of exterior doors.

#### Non Hold Open Models


Sized (Sizes 2,3,4,5,6) 3100 3300 3500 Adjustable (Sizes 1 thru 6) 3301 3501










# Non Hold Open Door Closers — Regular Arm 80-9303-2206-010 (04-09)



#### **Installation Sequence** 3










	Opening	Dimension "A"		
	To 100°	7-1/2 (191)		
	101° to 130°	6 (152)		
	131° to *180°	4-1/2 (114)		

Inches (mm)

\* Door/Wall/Hardware/Jamb conditions permitting













Caution: Don't completely close valve








# Non Hold Open Door Closers — Parallel Arm 80-9303-2206-010 (04-09)















# Non Hold Open Door Closers — **Top Jamb Arm** 80-9303-2206-010 (04-09)




2 Clips for metal covers 3500M

Yale ® is a registered trademark of Yale Security Inc., an ASSA ABLOY Group company. Copyright © 2004, 2008, Yale Security Inc., an ASSA ABLOY Group company. All rights reserved. Reproduction in whole or in part without the express written permission of Yale Security Inc. is prohibited.




3000 Highway 74 East • Monroe, NC 2811 Tel: (800)-438-1951 • Fax: (800)-3380965 www.yalecommercial.com

Number of Turns Required



### **Spring Power Adjust**



(Use 5/16" socket or adjustable wrench for this Adjustment)

Adjustment Chart (3301 & 3501 Only)						
	1000		_	,		
	~					

(3301 & 3501 Only)			MAXIMUM DOOR SIZE				
	DOOR	TYPE OF INST.	*	32" (0.85M)	36" (0.90M)	42" (1.00M)	48" (1.20M)
3100/3300/3500	INTERIOR	Regular Arm Top Jamb	TURNS OF OWER NT WRENC	5	8	11	13
		Parallel Arm		7	10	13	16
	EXTERIOR	Regular Arm Top Jamb		7	10	13	16
		Parallel Arm		9	12	15	18

\*20 FULL (360°) TURNS MAXIMUM AVAILABLE Closer is shipped set at mid range setting = 10 turns



The closing force for series 3301 & 3501 door closers is adjustable from a size 1 to a size 6, as outlined in ANSI Standard A156.4. When these series of door closers are installed and adjusted to conform to ADA reduced opening force requirements (5 lbs max.) for interior doors, they may not have adequate closing force to reliably close and latch the door. Power adjustments charted on this page are recommended where possible, to ensure proper door control.



By law the Americans with Disabilities Act (ADA) may require that door closer installation comply with accessability guidelines.

#### To identify your model: Closer Size Blank = 3301/3501 2 = 3302/35023 = 3303/35034 = 3304/35045 = 3305/35056 = 3306/3506Mfg

Date

